

## TruShield Rear Overhead Net (07-17 Wrangler JK 4-Door) Installation Guide

**Installation Time:** 10 Minutes

**Tools Required:**

✓ None

**Installation Instructions:**

1. Lay the net down on the ground. The label will face upward and be behind the front passenger seat.



2. Attach the front straps around the center roll bar.



3. Take the other two straps and attach around the rear roll bar.



4. Attach all four left side straps to the roll bar.



5. Attach all four right side straps to the roll bar.



6. Finished

