

GraBars BootBars - Red (07-17 Wrangler JK) Installation Guide

Installation Time: 20 Minutes

Tools Required:

- ✓ Socket Wrench
- ✓ T50 Torx Bit
- ✓ 9/16 Socket Bit
- ✓ 5/16

Installation Instructions:

1. Remove door hinge screws using a T50 Torx Bit.



2. Remove door strap and wire for door.



3. When installing BootBar, make sure the wording is readable to the driver or passenger.



4. Now take the screw and place it into the driver side BootBar hole and through the hinge.



5. Make sure one washer is above the hinge and one is below, then tighten the bottom nut with the 9/16 socket.



6. Repeat for opposite side.

7. Finished!

