

Rugged Ridge Magnetic Protection Panel Kit – Matte Black

Installation Guide for Jeep Wrangler 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Vehicle Washing Materials
- ✓ Box Cutter/Knife

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A).



Figure A

2. Ensure that all panels are included (Figure B).



Figure B

3. Wash the Jeep, focusing primarily on areas where the panels will affix and let air dry (inside) or dry with a soft microfiber cloth (Figure C) to ensure no grit exists between the paint surface and the magnetic panels as this can lead to scratches on the paint.



Figure C

- Affix panels to the Jeep (Figure D).



Figure D

- If panels need adjusting, remove panel entirely (Figure E) and reaffix. Do *not* slide panels as this can scratch the Jeep's paint.



Figure E

6. Remove panels when not in use. Clean and let dry. Store on flat surface in an even-temperature location to avoid warping (Figure F).



Figure F



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 06/29/2017