



[www.Starkey-Products.com](http://www.Starkey-Products.com)

PH: 386-951-6335

FX: 386-259-3918

## Fog Light Wiring H10 to Deutsch/H10 –Dual Adapter - Set MAP: \$49.99

Looking for a way to connect LED cube lights without removing your factory fog lights or installing a separate wiring harness? Now available is a plug-n-play solution from Starkey. This wiring adapter will connect Deutsch 2-pin connectors to your factory fog light wiring without the need to disconnect your factory fog lights! Skip the hassle of installing a separate wiring harness for LED cube lights with these simple adapters!

### Features and Benefits:

- Only high-quality weatherproof connectors are used.
- No cutting or splicing required – just plug the new adapters in and you're done.
- Adapter connects to factory H10 bulb and splits into H10 connector/ Deutsch DT Series 2-pin connector.
- 40 inch adapters give you flexibility in mounting your LED lights.

### Fitment:

- 1999-2016 Ford F-Series Trucks with factory fog lights (F150, F250, F350, F450, F550)
- 2000-2005 Ford Excursion with factory fog lights
- 2007-2009 Jeep Wrangler with factory fog lights
- 2007-2013 Toyota Tundra with factory fog lights
- 2005-2011 Toyota Tacoma with factory fog lights
- Other models that utilize an H10 fog light bulb connector

### What's Included:

- One set (two adapters) with weatherproof connectors
- Zip-ties to secure all wiring
- 5 Year Limited Warranty

### Installation:

- Installation difficulty = Very Low
- Installation time = 5 minutes
- Tools required = None

### Technical Specifications:

Works with virtually all aftermarket LED cube lights drawing less than 2.5 amps per light. Off-road use only.