

6 - LED Headlight 1997-2017

Tools Needed – Flat head screwdriver, T-15 Torx bit

Instructions:

1. Open hood and remove the 6 push pin clips across the top of the grille and remove them with a flat head screwdriver.
2. Unsnap grille, unplug turn signals that are located in the grille, and remove grille.
3. Remove the (4) T-15 Torx screws from the ring that is holding each headlight in the vehicle.
4. Unplug and remove the headlight.
5. For 1997-2006 Jeep Wranglers continue to step 7.
For 2007 to current Jeep Wranglers, the included H4 adapter and Canbus decoder are needed to complete install.
6. Plug in the new Raxiom headlight, and secure it in place with the previously removed ring and T-15 Torx screws.
7. Repeat previous steps to install the other headlight.
8. Turn on headlights and make sure they are aimed properly so not to blind oncoming traffic.
9. Reinstall grille by plugging turn signals back in and snap grille back into place.
10. Reattach the 6 push pin clips across the top of the grille to complete install.

Specifications:

(6) 10 watt Cree LEDs per housing

White partial angel eye halo connects to running lights and flashes
amber with turn signal connection

2000LM low beam draws 2.1a @ 13.8v

3000LM high beam draws 2.9a @ 13.8v

DOT approved for on-road use

LED color temp: 6500K

H4 connector

H4 to H13 and CANBUS adapters included for 2007 and newer Jeep
Wranglers

Dust/Water resistance: IP67