



Installation Instructions

DESCRIPTION : HD Rocker Guard (2-Door)

Step 1: Remove the nuts on the factory body mounts.

Step 2: With a helper, hold the new side set in place.

Step 3: Reinstall the factory hardware.

