

REDROCK[‡]

Installation Instructions

Description: HD Rocker Guards (4Door)

Installation Steps:

Step 1: Remove the nuts on the factory body mounts.

Step 2: With a helper, hold the new side set in place.

Step 3: Reinstall the factory hardware.

Photo 4 Door Passenger side





