



Installation Instructions

Description: ROCK GUARD FOR 07-15 JK

Seq #	Name	Qty.	Note	Seq #	Name	Qty.	Note
1	ROCK GUARD	2	Left&right	3	Rivnuts	42	M6x14
2	Bolts	42	M6x16				

Installation Steps:

1. Check the products and installation accessories according to the above list and install them according to the picture below.
2. Align the Rock Guard to the side of the vehicle. The arrow below points towards the front of the vehicle. Mark the drill locations. Remove the Rock Guard and drill the holes to 23/64". Install the rivnuts in the predrilled holes.
3. Install the product in the car.

