

Tools Needed:

-Basic Hand Tools

Step 1:

Begin by removing the negative battery terminal. Remove the (2) Phillips head screws from the factory tail light.



Step 2:

Disconnect the tail light plug and then remove the light from the vehicle.



Step 3:

Reconnect the tail light plug to the Raxiom light.



Step 4:

Reconnect the vehicle's chassis harness to Raxiom tail light. Ensure the circled tabs are located behind the vehicle's sheet metal before installing the factory screw. Reconnect the battery terminal and ensure the tail lights functions properly.

