

## Smittybilt SRC Classic Rock Rails (OEM Style) W/Step 07-15 JKU Wrangler 4 Door

**Installation Time:** 1-2 hours

**Difficulty Level:** 2 (Scale 1-10 10 being the hardest)

**Tools Required:**

- ✓ 10mm socket
- ✓ 13mm socket
- ✓ 3/8" & 1/4" socket wrench
- ✓ Impact drill driver(if you have one handy)

**Parts Used(Included from Smittybilt):**

- 12 - 6mm Ny-lock Nut
- 12 - 6mm Flat Washer
- 6 - 8mm Flat Washer
- 6 - 8 x 35mm Hex Bolt

*The Jeep in these instructions is a 2015 Wrangler 4 Door without sidesteps or rock rails installed from the factory*

**Installation Instructions:**

**Step One:** Unbox the rock rails/step and remove all packaging.

**Step Two:** Identify the rock rails/step in the picture above. Driver side is on the left. Passenger side is on the right.



**Step Three:** Identify the 6 existing holes in the pinch weld (2 front, 2 center, 2 back) and the 3 pre-threaded holes that come from the factory\*\*\*



**Step Four:** Take the driver side rock rail/step and loosely attach it to the jeep by lining up the 6 tabs on the rock rails with the already existing holes on the pinch weld area on your jeep.



**Step Five:** Insert 3 – 8 x 35mm hex bolt with 8mm flat washer into the pre-threaded holes from the factory and 6 – 6mm Ny-lock Nut with 6 – 6mm flat washers onto the bracket studs that go through the pinch weld.



**Step Six:** Now proceed to tighten all of the bolts and nuts completely using the 10mm socket wrench with ¼” ratchet for the hex bolts and the 13mm socket wrench with 3/8” ratchet for the lock nuts.



**Step Seven:** Now that the driver side is done step back and take a look and admire your work.



**Step Eight:** Follow these same steps starting at **Step Four** to help assist you in installing the passenger side rock rail/step.



\*\*\*Note: As stated in Step Three my jeep has pre-threaded holes from the factory, on some 2012 and older models you will use the nut-clip setup provided by Smittybilt with 10mm bolts. There will be an open cavity area in the bottom of the body tub. You will install the nut-clips the same way the 8mm bolts were installed

You have now successfully installed the Smittybilt SRC Classic Rock Rail(OEM Style) W/Step for a 2007-2015 Jeep Wrangler JKU 4 Door. Thanks for using my install guide and Enjoy!!

**Installation Instructions Written by ExtremeTerrain Customer Daniel Loftus  
JEEP WRANGLER CLUB OF WNY - 2015 JKU SPORT**