4x4 SUSPENSION PARTS

07-17 Jeep JK Wrangler Front Adjustable Track Bar

Front

With the vehicle in park (auto) or in gear (standard), chock the rear wheels and raise the front axle with a jack. Support the axle with jack stands. Remove the fractory track bar by removing the 21mm bolt on either end.

Adjust the track bar so that it is close in length to the factory track bar. This will make it easier to center the axle once installed.

Reinstall the adjustable track bar with the factory hardware, torque to 125 ft-lbs. Use the adjustment sleeve to center the axle. Tighten the adjustment sleeve clamp bolts to 45 ft-lbs.

Test drive the vehicle and double check the clamp bolts are still tight. Then check again after 75 miles.





